# QUICK MANUAL— CLASSIC CONTROL PANEL

INNOVA CONTROLS

## HEATER ON / OFF




Push for heater ON / OFF

Heater ON led steady

Temp. led blinking slow

## SAUNA ROOM LIGHT ON / OFF



Push for light ON / OFF

Light ON led indicator

## SET SAUNA ROOM TEMPERATURE




Push to select temperature

Temperature led steady or blinking slow

Hold down to activate select.

Temperature led blinking fast

Push to de-crease tem-perature

Push to in-crease tem-perature

Push long to confirm

OR

After 5 sec. auto confirm

## SET SESSION TIME




Push to select session time

Session time led steady

Hold down to activate select.

Session time led blinking fast

Push to de-crease ses-sion time

Push to in-crease ses-sion time

Push long to confirm

OR

After 5 sec. auto confirm